

FIG.1




FIG.2

MODEL	LCD SCREEN SIZE (HORIZONTAL × VERTICAL) (dot)	COLOR
N2001	120 × 130	4096 COLORS
N2002	120 × 130	65536 COLORS
P2101V	176 × 164	262144 COLORS
D2101V	132 × 142	262144 COLORS
P2002	120 × 130	65536 COLORS
D504i	132 × 160	262144 COLORS
F504i	132 × 136	65536 COLORS
N504i	160 × 198	65536 COLORS
SO504i	128 × 128	65536 COLORS
P504i	132 × 144	65536 COLORS

FIG.3A

<SERVER SYSTEM>

<TERMINAL>




FIG.3B

<TERMINAL>

<SERVER SYSTEM>

FROM FIG3A STEP12




FIG.4




FIG.5




FIG.6

A diagram of a form labeled 32. It contains four input fields: 'DESTINATION ADDRESS' (32A), 'SENDER ADDRESS' (32B), 'SUBJECT' (32C), and 'MESSAGE' (32D). At the bottom are two buttons: 'CANCEL' (32E) and 'OK' (32F).

DESTINATION ADDRESS	<input type="text"/>
SENDER ADDRESS	<input type="text"/>
SUBJECT	<input type="text"/>
MESSAGE	<input type="text"/>
<div>CANCEL OK</div>	

FIG.7

A diagram of a form labeled 33. It contains a table of radio button options (33A) with labels (33B). At the bottom are two buttons: 'CANCEL' (33C) and 'OK' (33D).

<input type="radio"/> N2001	<input type="radio"/> N2002	<input type="radio"/> P2101V	<input type="radio"/> P2002
<input type="radio"/> D504i	<input type="radio"/> F504i	<input checked="" type="radio"/> N504i	<input type="radio"/> SO504i
<input type="radio"/> P504i	<input type="radio"/> - - - -	<input type="radio"/> - - - -	<input type="radio"/> - - - -
<input type="radio"/> - - - -	<input type="radio"/> - - - -	<input type="radio"/> - - - -	<input type="radio"/> - - - -
<input type="radio"/> - - - -	<input type="radio"/> - - - -	<input type="radio"/> - - - -	<input type="radio"/> - - - -

CANCEL OK

FIG.8




FIG.9




FIG.10

35

35A

35B

DESTINATION ADDRESS	○○○○@docomo.ne.jp
SENDER ADDRESS	xxxx@○○.com
SUBJECT	△△△△
MESSAGE	----- ----- -----

CANCEL OK

35C 35D

The diagram shows a rectangular window representing a user interface. At the top center is a small square icon (35A) depicting a landscape with a cloud and a sun. To the right of the icon is the label 35A. To the right of the icon and below the label 35A is the label 35B. Below the header is a table with four rows. The first row is for the destination address, the second for the sender address, the third for the subject, and the fourth for the message body. The message body field contains three dashed lines. Below the table are two buttons: 'CANCEL' (35C) and 'OK' (35D). The entire window is labeled 35.

FIG. 11




FIG.12




FIG.13

35'

35A

35B

DESTINATION ADDRESS	○○○○@docomo.ne.jp
SENDER ADDRESS	××××@○○.com
SUBJECT	△△△△
MESSAGE	----- ----- -----

CANCEL OK

35C 35D

FIG.14





FIG.15A

<TERMINAL>

<SERVER SYSTEM>



<TERMINAL> **FIG.15B** <SERVER SYSTEM>

FROM FIG15A STEP42




FIG.16

PRIOR ART

